

# Firestone

## SPECIALTY PRODUCTS

---

### PondGard™ Rubber Liner Installation Detail 4

#### Deploying a Geotextile Up a Slope



**Step 1**- Unroll the geotextile.



**Step 2**- If necessary; apply a temporary ballast or mechanical attachment to the soil.



**Step 3**- Trim the geotextile to fit.

#### **This detail featured these Firestone Products:**

**Product**

- Firestone Geotextile

**Item #**

Varies by Size