

# Firestone

## SPECIALTY PRODUCTS

---

### PondGard™ Rubber Liner Installation Detail 3

#### Deploying a Geotextile Downslope



**Step 1-** Starting at the apex of the slope, deploy the geotextile downhill.



**Step 2-** If necessary; apply a temporary ballast or mechanical attachment to the soil.



**Step 3-** Trim the geotextile to fit.

#### **This detail featured these Firestone Products:**

**Product**

- Firestone Geotextile

**Item #**

Varies by Size