


Firestone

SPECIALTY PRODUCTS

PondGard™ Rubber Liner Installation Detail 10


Extend Seaming Technique into the Anchor Trench



Step 1- Ensure the liner is dry and free of mud or other contaminants.



Step 2- Apply the QuickPrime™ Plus Primer several inches (approximately 7.62 cm) down into the anchor trench.



Step 3- Make sure to apply below any point at which the PondGard could be exposed.

This Detail featured these Firestone Products:

Product

- PondGard Rubber Liner
- QuickPrime Plus Primer
- QuickScrubber™

Item #

Varies By Size
W563587041
or
W563587044
W563582045