

Firestone

SPECIALTY PRODUCTS

PondGard Rubber™ Liner Installation Detail 12

Installing PondGard Rubber Liner to a Corner Wall



Step 1- Ensure the liner is dry and free of mud or other contaminants.



Step 2- To solidify the PondGard corner seam, apply QuickPrime™ Plus Primer along each wall.



Step 3- Test the primer flash-off by touching the primed area with your finger and pushing forward at an angle. The primer should not string as your finger is moved up and away.



Step 4- Adhere the 3.00" (7.62 cm) QuickSeam™ Splice Tape to the primed surface of the bottom panel.


Firestone

SPECIALTY PRODUCTS

PondGard Rubber Liner Installation Detail 12 (Con't) Installing PondGard Rubber Liner to a Corner Wall



Step 5- Remove the release paper and adhere the PondGard flap to this Splice Tape to create a sealed seam.



Step 6- Using a hand roller; roll the seam to ensure adhesion at all points.

Note: See detail 14- "Installing an Inside QuickSeam Corner Flashing" for proper installation of an inside corner.

This Detail featured these Firestone Products:

Product

- PondGard Rubber Liner
- QuickPrime Plus Primer
- QuickScrubber™
- Hand Roller

Item #

Varies By Size
W563587041
or
W563587044
W563582045
W563582023