

Firestone


SPECIALTY PRODUCTS

PondGard™ Rubber Liner Installation Detail 8

Removing a "Fish Mouth" Gap From a QuickSeam™ Cover Strip



Step 1- Squeeze with your fingers or attempt to hand roll the "fish mouth" gap to the edge of the QuickSeam Cover Strip.



Step 2- If the gap forms a void all the way under the tape to the overlap's edge; tape over and beyond the void with a patch of QuickSeam Cover Strip.

Notes:

1. Make sure to extend the tape a minimum of 3.00" (7.62 cm) on all sides.
2. Caulk if necessary.

This Detail featured these Firestone Products:

Product

- PondGard Rubber Liner
- 6.00" (15.24 cm) QuickSeam Cover Strip
- QuickPrime Plus Primer
- QuickScrubber™
- Hand Roller

Item

Varies By Size
W56RAC1616
or
W56RAC1693
or
W563587041
W563587044
W563582045
W563582023